

FH-01 Quick Start Programming Guide

The FH-01 thermostat is made with default factory settings which will function very well out of the box, but might not suit your lifestyle. This is a quick-start guide to altering the factory settings to suit your individual needs. All of the features of the FH-01 are explained in greater detail in the main operating instructions.

Setting The Clock

- With the thermostat turned on, press the Clock button twice
- You are now able to set the minutes using the Up/Down keys
- Press H to accept
- You are now able to set the hours using the Up/Down keys
- Press H to accept
- You are now able to set the day of the week using the Up/Down keys
- Press A to store and exit

Temperature Hold/Manual Override

The temperature hold function allows you to manually override the programme and set a temperature for a desired period.

- Press H
- Using the Up/Down arrow keys enter the required hold time
- Press H
- Using the Up/Down arrow keys enter the required hold temperature
- Press A to accept

You will see the Hold indication is displayed which will countdown the hold duration.

To cancel, reduce the Hold time to 00 hours

Altering the default program

The thermostat is supplied with a default program, but these can be changed easily. The default times are;

- 08.00 - 21°C (Wake)
- 09.30 - 16°C (Leave)
- 16.30 - 22°C (Return)
- 23.00 - 17°C (Sleep)

You can adjust the time and temperature for each of the 4 operations above.

- To begin programming, press Clock Once
- You will see Mon-Fri shown, the thermostat is setup for Weekday/Weekend Programming by default. If you want to change to 7-day programming see the optional features section of the main instructions.
- Using the Up/Down arrow keys, enter the required Wake time
- Press H
- Using the Up/Down arrow keys, enter the required Wake Temperature
- Press H
- You will now see "Leave"
- You should repeat the programming for each period, entering --.-- for unused periods.

Note: For weekday/weekend Programming, the 4 comfort levels are the same for all weekdays. For 7 day programming each day can have 4 different comfort levels.

Wiring

For wiring instructions please see the diagram towards the back of the main instruction booklet.

